Alfa Laval Niagara Wet Surface Air Coolers (WSAC®)

Genuine parts for guaranteed performance



Motor, prop fans, centrifugal fan wheels, wheel housings, bearings, fan shafts, gear reducers, belts, fan shrouds, vibration switches and drift eliminators.



Water make-up valves, pump screens, temperature switches, pan heaters, casing panels, caulk and sealing tape.



Prepared for emergency breakdown situations? Don't wait until your tube bundle fails. Schedule replacement of critical components in advance, and avoid downtime delays by stocking parts with longer lead-times.

Contact our help desk at + 1-800-426-5169 or <u>niagara.parts@alfalaval.com</u>.



Spray system

Spray pumps, pump shafts and impellers, spray distribution piping, spray nozzles and pressure gauges.

Tube bundles

Replacement tube bundles, tube bundle covers and gaskets. Completely cleanable and serpentine tube bundles designed to meet ASME/ TEMA/API specifications and original dimensions to minimize installed cost.



Alfa Laval Niagara Wet Surface Air Coolers (WSAC[®])

System maintenance



1. Lubricate fan motors monthly.

Water treatment and

necessary.

under control.

blowdown maintenance

1. Check bleed rate weekly and adjust if

treatment specialist if growth is not

- 2. Check oil level on gear drives monthly, add oil if necessary.
- 3. Check fan blades for tightness annually, adjust pitch if necessary.
- 4. Check shaft/coupling condition annually, if applicable.
- 5. Check air louvers for proper operation monthly, if applicable.
- 6. Check that drift eliminators are clean and secure monthly, if applicable.



Be sure to follow all plant safety procedures when servicing your Alfa Laval Niagara WSAC system.

In addition to annual inspection, WSAC systems should be serviced on a regular basis.

Avoid downtime in critical processes – schedule an integrity audit by a qualified Alfa Laval Niagara field service technician today.



Spray maintenance

- Check spray distribution system weekly. Check spray nozzles coverage and clean as necessary.
- 2. Check operating water level in basin weekly, adjust float valve if required.
- 3. Clean and flush basin annually.
- 4. Check for casing leaks monthly, repair as necessary.

Tube bundle maintenance

1. Check tube bundle pressure drop monthly, clean internally if necessary.

Pump maintenance

- 1. Lubricate pump motors monthly.
- 2. Check pump seal weekly, replace if necessary.
- 3. Check pump screen weekly. If environment is extremely dirty, clean screens daily.

